

Installation Instructions for Rear Corner Storage

The cloth covering on the bottom of the roll cage needs to be turned up, or slid up, out of your way and the body bolt removed near the corner. Then set the Corner Storage Unit in place and install the body bolt.



Now check to see if there is a wire that follows down the roll cage, and if there is a wire you will need to put the band clamp under it so not to pinch it when tightening the clamp.

Installation Instructions for Rear Corner Storage



Now install the band clamp around the roll cage and through the support bracket on the storage unit. While tightening the band clamp you can adjust the storage unit up, down, forward or back to the desired location. The cloth covering can now be turned back down to partly cover the clamp.