

Installation Instructions for 2 door JK

Over the Fender Well Storage

Use the body bolt over the fender well to secure the top of the storage unit. If mounting on your Jeep with a soft top or without a top you can mount directly on the steel body. If mounting on your Jeep with a hard top mount on top of the fiberglass lip of the top.

With the bolt loosely installed, hold the top of the unit level while using an electric screwdriver to install the three self-drilling screws in the bottom of the storage unit and then finish tightening the body bolts.



Installation Instructions for 2 door JK

Over the Fender Well Storage



If you have a hardtop but sometimes run without it you can do your mounting with the hardtop on and when you want to take it off remove the body bolt and loosen the screws enough to tilt the storage unit inward enough to lift off the top. This way you won't have a hard time finding the original holes through the carpet. You can use flat washers as spacers for the body bolt to level the storage unit while running topless.