



## Installation Instructions for 2 door JK

### Over the Fender Well Storage



If you have a hardtop but sometimes run without it you can do your mounting with the hardtop on and when you want to take it off remove the body bolt and loosen the screws enough to tilt the storage unit inward enough to lift off the top. This way you won't have a hard time finding the original holes through the carpet. You can use flat washers as spacers for the body bolt to level the storage unit while running topless.